




Architectural Seals

IS5035, IS5040, IS5045, IS5050 & IS5055 Sweep Action Brush



Installation Instructions

1. Remove from packaging and measure lengths against existing head and jambs.
2. Slide out brush strip from aluminium holder and using a fine tooth hacksaw, cut holder to required length removing burrs from cut ends.
3. Cut brush strip to suit using combination pliers, (which will automatically lock in bristles).
4. Before replacing brush strip, bend slightly and slide back into aluminium holder, (this will prevent the brush strip from sliding out of the holder).
5. Prior to fixing seal in place, ensure all surfaces are smooth and clean, (methylated spirit or alcohol is suitable, do not use oil based solvents).
6. Position seal and pencil mark fixing location.
7. Peel off backing paper and lightly position on pre-marked location. Press firmly into place along full length of strip, (maximum bond is achieved after 24 hours).
8. Optional Fixing - Drill holes on aluminium holder and screw fix, (screws not supplied).



LORIENT

Tel: +44 (0) 1626 834252

Fax: +44 (0) 1626 833166