

LETTERPLATE LINER FITTING INSTRUCTIONS

KIT CONSISTS OF:

TOP / BOTTOM

2 X LENGTHS @ 300MM

SIDES

1 X LENGTH @ 118MM (INCLUDING METAL RE-INFORCEMENT)

**PLEASE NOTE: THE MAXIMUM OVERALL DIMENSION OF THE LINER MUST NOT EXCEED 300MM WIDE X 58MM HIGH.
LINER MUST BE USED IN CONJUNCTION WITH A LETTERPLATE WHICH HAS ALUMINIUM OR STEEL FLAPS AND STEEL HINGE PINS.
CUT COMPONENTS USING A HACKSAW.**

INSTRUCTIONS

1. CUT TOP AND BOTTOM COMPONENT TO SUIT APERTURE WIDTH, ENSURING A TIGHT FIT. REMOVE SELFADHESIVE BACKING AND FIT IN POSITION.
2. CUT SIDE COMPONENT TO SUIT HEIGHT OF APERTURE WITH THE TOP AND BOTTOM ALREADY FITTED. REMOVE SELFADHESIVE BACKING AND FIT IN POSITION ENSURING THE METAL RE-INFORCEMENT IS TO THE OUTER EDGE.
3. FIT LETTERPLATE.

