




## Architectural Seals

IS4050S  
IS4055S  
IS4060S  
IS4065S

### Stainless Steel Threshold Plates



Stainless steel threshold plates, when used in conjunction with stainless steel threshold seals, help prevent rain, draught and smoke infiltration. Impervious to most chemicals, solvents, cleaning fluids and disinfectants.

#### Installation Instructions

- 1 Remove seals from packaging and measure full width between jambs or door stops.
- 2 Cut to size using machine tool / hacksaw. Where threshold plate meets jamb or stop, sealant may be applied to prevent water leakage.
- 3 Position plate on door sill in required location and screw fix using screws supplied.



Tel: +44 (0) 1626 834252  
Fax: +44 (0) 1626 833166