




Architectural Seals

IS4130 Threshold Plate



IS4130

A low profile threshold plate, used in conjunction with a threshold seal to help prevent rain, draught and smoke infiltration.

Installation Instructions

- 1 Remove seal from packaging and measure to full width between jambs or door stops.
- 2 Cut to size using machine tool/hacksaw (where threshold plate meets jambs/door stop, sealant may be applied to prevent water leakage).
- 3 Drill and countersink threshold plate to suit fixing screws.
- 4 Position plate on door sill in required location and screw fix into place.



Tel: +44 (0) 1626 834252
Fax: +44 (0) 1626 833166