




# IS7130

## Fitting Instruction

Perimeter Seal



Length	
--------	--

### DESCRIPTION OF CONTENTS

- Aluminium carrier (1)
- Pre-drilled holes (2)
- Flexible gasket (3)
- Bag of screws
- Fitting instruction

### TOOLS REQUIRED FOR INSTALLATION

- Tape measure
- Saw (power or hand)
- Screw driver
- Drill (power or hand)
- Knife
- Pencil or marker

### INSTALLATION DETAIL

It is not necessary to remove the door from its hinges unless otherwise specified.

#### STEP 1

Remove the seal from the packaging and measure the existing head (top) and jambs (sides) of the door frame to determine the seal lengths required.

#### STEP 2

Pull back flexible gaskets and cut the aluminium carrier to the lengths required.

#### STEP 3

Pulling back into position, cut the flexible gaskets to the required lengths.

#### STEP 4

Position the seals to the door stops along the top and sides of the door frame (as illustrated) and mark out the hole locations with a pencil. (Ensure the top corners are neatly butt-jointed).

#### STEP 5

Lightly screw-fix each length to the door stops through the slotted holes with the screws supplied. (Fixing holes are pre-drilled).

#### STEP 6

Close the door and check for a uniform seal around the door by inserting this sheet of paper between the seal and the door face. Resistance should be firm at all points.

#### STEP 7

Tighten screws as necessary.

### IMPORTANT

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.

**We recommend the IS7130 perimeter seal be fitted with the Lorient Integrity™ IS8010si or IS8090si automatic door bottom seal.**

*The seal may be removed for periodic cleaning or replacement of a worn gasket, without removing the door from its frame.*

### OTHER INTEGRITY™ ARCHITECTURAL SEALS INCLUDE:

- Door Perimeter Seals
- Door Bottom Seals
- Automatic Door Bottom Seals
- Threshold Plates
- Brush Seals
- Magnetic Seals

Contact your nearest Lorient office for further details.

### NOTE

*Recommendations as to methods for use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.*

*Lorient reserves the right to make alterations or delete any installation detail without prior notice.*



**Architectural Seals**

**AUSTRALIA**  
Lorient Australia Pty Ltd

QLD: (61-7) 3635 5000  
NSW: (61-2) 9907 3844  
VIC: (61-3) 9785 2688

**ASIA PACIFIC—Hong Kong**  
Lorient Pacific Limited

Tel: (852) 2505 0328

**EUROPE—UK**  
Lorient Polyproducts Limited

Tel: (44-1626) 834 252