


AURA® PERIMETER SEAL

FITTING GUIDE 7506

AAS7506



CONTENTS

- AAS7506 perimeter seal with pre-drilled countersunk fixing holes & self adhesive tape
- Semi-rigid Batwing® gasket
- Bag of screws

TOOLS REQUIRED

- Tape measure
- Pencil or marker
- Saw (power/hack)
- 2.5mm drill bit
- Drill
- Screw driver
- Knife
- Router (rebated installation)

For more information please call:

+44 (0)1626 834252

All rights reserved. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited. © Lorient Polyproducts Ltd 2019

www.lorientgroup.com
+44 (0) 1626 834252

Lorient Polyproducts Ltd
Endavour House
Farrax Road
Heathfield Ind Estate
Newton Abbot
Devon TQ12 6UD
United Kingdom

LORIENT

**AAS7506
PERIMETER
SEAL**

INSTALLATION DETAIL

This product can either be face fixed or rebated.

FACE FIXED

It is not necessary to remove the door from its hinges unless otherwise specified.

STEP 1

Remove the seal from the packaging and measure the height of the meeting stile.

STEP 2

Cut the aluminium carrier to the required length.

STEP 3

Cut the semi-rigid Batwing® gasket to the required length.

STEP 4

Determine the door handing and position the carrier against the appropriate meeting stile and mark out the hole locations with a pencil. Use the self adhesive tape to help hold the position while fixing.

STEP 5

Drill pilot holes with a 2.5mm drill bit (if required).

STEP 6

Screw fix the aluminium carrier length to the meeting stile using the screws supplied.

STEP 7

Press the semi-rigid Batwing® gasket into the aluminium carrier. There are no fixings here, it is a simple interference fit.

STEP 8

Close the door and ensure the seal makes uniform contact with the opposite door leaf.

NOTE

We recommend the AAS7506 perimeter seal be fitted with any AURA® or LAS perimeter seal and drop seal.

IMPORTANT

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes & latches properly.

DISCLAIMER

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers. Lorient reserves the right to make alterations or delete installation detail without prior notice.