


LAS7050

PERIMETER SEAL

FITTING GUIDE



LENGTH _____

CONTENTS

- LAS7050 perimeter seal

TOOLS REQUIRED

- Tape measure
- Scissors, knife or snips
- Pencil or marker

NOTE

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Lorient reserves the right to make alterations or delete any installation detail without prior notice.

For more information please call:

+9714 883 7206

STEP 1

Remove the seal from the packaging.

STEP 2

Measure the leading edge of the sliding door.

STEP 3

Cut the product to fit using scissors, a knife or snips.

STEP 4

Ensure the glass is clean and free from any dust.

STEP 5

Remove the pieces of protective backing one foot at a time.

STEP 6

Adhere the seal to the exact location on leading edge. **Do not remove and relocate.**

STEP 7

Inspect the seal to assure proper location.

STEP 8

Ensure the door assembly operates effectively.

NOTE

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the door seal periodically to ensure the door assembly to which it is fitted, closes and latches properly.



V1