


# AURA® PERIMETER SEAL

## FITTING GUIDE 7501

### AAS7501

certifire  
CF5179



#### CONTENTS

- AAS7501 perimeter seal
- Bag of screws

#### TOOLS REQUIRED

- Tape measure
- Pencil or marker
- Saw (power/hack)
- 2.5mm drill bit
- Drill
- Screw driver
- Knife

V1



Lorient Pacific Ltd  
Unit A2, 5/F Wing Tai Centre  
12 Hing Yip Street  
Kwun Tong  
Hong Kong

+852 2505 0328  
www.lorienthk.com

All rights reserved. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited.  
© Lorient Polyproducts Ltd 2019

For more information please call:

**+852 2505 0328**

## INSTALLATION DETAIL

It is not necessary to remove the door from its hinges unless otherwise specified.  
AAS7501 is designed to be mitre jointed for premium aesthetics.

### STEP 1

Remove the seal from the packaging and measure the existing head (top) and jambs (sides) of the door frame to determine the seal lengths required. Mark with pencil.

### STEP 2

Set the decorative cover plate to one side.

### STEP 3

Pull back silicone gasket and cut the aluminium carrier to the lengths required, allowing for corner joints. Ensure each corner of the perimeter seal is mitred at a 45° angle to form a corner (90° angle).

### STEP 4

Cut the decorative cover plate to the lengths required, also mitre joints.

### STEP 5

Replace silicone gasket back into position and cut to required length.

### STEP 6

Position the seals to the door stops along the top and sides of the door frame and mark out the slotted hole locations with a pencil. (Ensure the top corners are neatly joined together at 45° angles). Drill pilot holes with a 2.5mm drill bit (if required).

### STEP 7

Lightly screw-fix each length to the door stops through the slotted holes with the screws supplied. (Fixing holes are preslotted to enable the seal to be accurately adjusted as required).

### STEP 8

Close the door and check for a uniform seal around the door by inserting this sheet of paper between the seal and the door face. Resistance should be firm at all points.

### STEP 9

Tighten the screws and replace the decorative cover plates.

### NOTE

We recommend the AAS7501 perimeter seal be fitted with any AURA® or LAS drop seal.

### INSTALLATION TIP

Should circumstances require that the decorative cover plate be removed, simply insert a flat blade under the top edge and gently prise it off, taking care not to damage the carrier or gasket.

### IMPORTANT

Ensure that the installation of this product does not impede the opening or closing of the door. It is recommended to check the adjustment of the door seal periodically to ensure the door assembly to which it is fitted, closes & latches properly.

### DISCLAIMER

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers. Lorient reserves the right to make alterations or delete installation detail without prior notice.



Gasketing materials for fire doors intended for application to wood and plastic covered composite and wood core doors rated up to 1.5 hours. Listed steel frames and/or classified steel covered composite, hollow metal doors rated up to 3 hours.