


LAS9001 DRIP GUARD

FITTING GUIDE



CONTENTS

- LAS9001 drip guard
- Steel screws

TOOLS REQUIRED

- Tape measure
- Pencil or marker
- . Saw, power or hand
- Power drill
- 4mm drill bit
- 6mm masonry drill
- Fixing plugs

INSTALLATION DETAIL

NOTE

It is not necessary to remove the door from its hinges - however ensure the proposed position of the guard does not interfere with the operating arc of the door.

STEP 1

Remove the drip guard from the packaging and measure the door frame width.

STEP 2

If fixing directly to the frame the guard width should be the same as the overall frame width. If fixing to the wall add 100mm to the frame width to provide a 50mm overhang on either side of the door frame.

STEP 3

Remove flexible cover strip. Mark the guard with a pencil to the desired length and cut through using a saw.

STEP 4

Using a power drill with a 4mm drill bit, create fixing holes in the guard at the required positions.

STEP 5

Position the guard centrally above the door and mark out hole centres.

STEP 6

Using a power drill with a 6mm masonry bit, create fixing holes in required position. Insert fixing plugs. (Metal door jambs, if mortar filled, will require a clearance hole before drilling with a masonry bit. If unfilled, drill pilot holes and screw fix with steel self tappers supplied).

STEP 7

Apply a bead of water resistant sealant along the back face and fix the guard in position using supplied steel screws.

STEP 8

Refit the flexible cover strip to hide screw heads and trim to length.

NOTE

For effective operation, the LAS9001 drip guard requires a minimum of 38mm overhang either side of the door.

NOTE

NOTE

Recommendations as to methods, use of materials and construction details are based on the experience and knowledge of Lorient and are given in good faith as a general guide and service to designers, contractors and manufacturers.

Ensure that the installation of this product does not impede the

opening or closing of the door.

the adjustment of the door seal

periodically to ensure the door

assembly to which it is fitted, closes

It is recommended to check

and latches properly.

Lorient reserves the right to make alterations or delete installation detail without prior notice.



V1



Lorient Southeast Asia Pte Ltd 9 Kallang Place #04-02 Singapore, 339154

> +65 6270 1279 www.lorient.com.sg

All rights reserved. No part of this fitting guide may be reproduced, stored in a retrieval system, or transmitted in any means, electronic, mechanical, photocopying, recording or otherwise without the written permission of Lorient Polyproducts Limited.

© Lorient Polyproducts Ltd 2019

For more information please call: